

HOW TO ASSEMBLE PLASTIC BEEHIVE

1. Place all 4 pieces of the super and screw together with screws provided as in picture 1. It helps if you pre-drill a small hole to stop the screws from screwing in on an angle.



2. To assemble the bottom board, place the cleats over the bottom as in picture 2. Then mark and drill the holes and bolt the cleat to the bottom with bolts provided.



The front cleat has the landing strip protruding out. This is the end that has the slots for the entrance. The rear cleat has the landing board facing inwards. See assembled picture.

